








Installation Socket for Cycle Counter

Code: G124.1



**Mounting:**  
Please fix cycle counter in the hole of socket and use 2 pcs. of cylinder head cap screws and dowel pin.

**Operation Mode:**  
Cycle counter is non-detachable when mounted.



Order: G124.1

## Mechanical Counters



### Economic Type

- \* 5 - digit
- \* Overhead pulsative
- \* Side zeroing



Order: 13701



### Professional Type

- \* 5 - digit
- \* Overhead pulsative
- \* Side zeroing



Order: RS207



### Economic Type

- \* 5 - digit
- \* Overhead pulsative
- \* Side zeroing



Order: D29003




### Economic Type

- \* 5 - digit
- \* Pulling Counter
- \* Knob Type



Order: D29002



### Counter

- \* 5 - digit
- \* With the rubber wheel for meter



Order: D29001